

Low Impedance Measurement Using Low Cost SDR VNA

Shrinithi Venkatesan


February 13, 2024

1

Agenda


- Need for Low Impedance Measurement
- Two Port Measurement Method
- Lowest Impedance measured by the SDR VNA
- RLC Characteristics Trends of Circuit Elements
- Takeaways

Need for Low Impedance Measurement



- PDN components have target impedances in the mOhm range.
- Not practical to measure $Z < 0.1$ Ohms using return loss 1-port VNA.
- Real world limitations of Signal to Noise ratio & fixturing reproducibility.
- 2- Port method is a **low-cost method** to measure impedances even < 0.1 ohms.

4 – Point Kelvin Method for Low Z Measurement



Measurement Set up for Calculating the Resistance.


Rated Resistors (in Ohm)	Measured Resistance (Uncertainty ± 0.002) (in Ohm)
10	10.006
1	1.003
0.50	0.505

Measured resistors are within 1% tolerance of the rated values.

Next, we will correlate the measured & simulated impedance.


Low Impedance Measurement – 1 & 2 Port Method

1- Port Method ($Z > 0.1$ ohms)





$$S_{11} = \frac{Z_2 - 50}{Z_2 + 50}$$

2- Port Method ($Z < 0.1$ ohms)



$$Z_{DUT} = 25 \frac{S_{21}}{1 - S_{21}}$$



SDR VNA Calibration – Open, Short, Load & Through




- Open, short & 50-ohm load plotted on a Smith Chart.
- SDR VNA is calibrated.

- Thru - Insertion Loss is 0dB (100% Transmission)
- Noise Floor is the lowest impedance measured by the SDR VNA.

Correlation in Measured & Simulated Resistor Impedance





1 Ohm Resistor
Breakout Board



Plotting Measured
Impedance in ADS


Measured & Simulated 1 Ohm Resistor Impedance




This simple RL model is an excellent model for the impedance behavior of this real resistor from low to high frequency.

Measured & Simulated Impedance correlate accurately.

R & L Characteristics of SMT Resistors




Similar ESL values due to identical footprint.
Zero Ohm Jumper has the lowest resistance.





Rated Resistors (in Ohm)	Modeled R (in Ohm)	Modeled ESL (in nH)
10	10.00	1.47
1	1.00	1.47
0.5	0.50	1.47
Zero Ohm Jumper	0.011	1.45

Lowest Impedance Measured by SDR VNA



Lowest Impedance measured by the SDR VNA is the Noise Floor.



Solder Blob
(Made wide & thick to have Low R & L)

Resistor Structures	Modeled R (in mOhm)	Modeled ESL (in nH)
Zero Ohm Jumper	11	1.45
Solder Blob	0.55	0.45
Noise Floor	0.15	0.00025


Noise Floor Resistance: 0.15 mohm
Noise Floor Inductance: 0.25 pH

Takeaways


- The 2-port method can eliminate the artifacts associated with contact impedance of the probes or fixturing to the DUT.
- 2- Port Method is a low-cost and reliable method for Low Z Measurement.
- First order RL models can be used to hack the impedances measured with the 2-port method to correlate measured & simulated data.
- SDR VNA can measure resistances & inductances in the mOhm and pH range respectively.
- ESL of components depends on their footprint.

Questions?

RLC Equivalent Z for an SMT MLCC




15 uF SMT MLCC
Breakout Board



Plotting Measured
Impedance in Qucs

Reduced Inductance of MLCC – X2Y




Board Structure	ESR (in mOhm)	ESL (in nH)	C (in uF)
Multiple Vias	16.3	1.225	0.20
X2Y	9.63	0.675	0.368

X2Y capacitors have a much lower inductance than Multiple Vias structure.

There is a reduction of a factor of 2 in ESL.

This translates into a reduction in the impedance at high frequency by a factor of 2 and could enable a parts count reduction by a factor of 2 as well.

RLC Equivalent Z for Electrolytic & Tantalum Capacitors





Rated Capacitance (in uF)	ESR (in Ohm)	ESL (in nH)	C (in uF)
15 (SMT MLCC)	0.00366	0.75	13.2
0.47 (Electrolytic)	4	8.4	0.39
2.2 (Tantalum)	0.57	7.70	2.28

This is the best match we can get with a first order simulated RLC model.

ESR for the SMT MLCC is much lower than the Electrolytic & Tantalum Capacitors.

Electrolytic & Tantalum Capacitors have a much higher ESL due to the leads.


RLC Equivalent Z for an SMT MLCC



Rated Capacitance (in uF)	ESR (in mOhm)	ESL (in nH)	C (in uF)
15	3.6	0.75	13.2


This simple RLC model is good enough to match the impedance behavior of the real SMT MLCC component.

ESL of 0.22 μ F MLCC with different Via positions




Via Position	ESR (in mOhm)	ESL (in nH)	C (in uF)
20 mils from Pad	38.8	4.05	0.20
5 mils from Pad	22.3	2.15	0.20
In the Pad	17	1.7	0.20
Multiple Vias	16.3	1.225	0.20


Vias
20 mils from Pad



Vias
in the Pad



Vias
5 mils from Pad



Multiple
Vias

